

# Crestron Controls

The Crestron Touchscreen allows you to power and position your camera

Step 1: Power Projector **ON**

Step 2: Power Camera **ON**

Step 3: Select **Screen** to focus camera onto the projector screen or whiteboard

